

User's Manual

Digital Controller

FZ400/600/700/800/900

NPH


call toll free: 1.877.674.9744



FZ400




FZ600



FZ700



FZ800



FZ900

1 Notice


Please confirm the specification of controllers is to totally with your requirement before using it, also read this user's manual in detail.

⚠ Danger

1. Danger! Electric Shock!
DON'T touch AC power wiring terminal when controller has been powered!
Keep the power off until all of the wiring are completed!

⚠ Warning

1. Please confirm the AC power wiring to controller is correct, otherwise it would be caused aggravated damage on controller. (FY400 connecting with Pin 1 and 6, FY600/700/800/900 with Pin 1 and 2).
2. Be sure to use the rated power supply(AC85~265V or DC24V), otherwise it would be caused aggravated damage on controller.
3. Please confirm wires are connected with correct terminal (Input, Output).
4. Use M3 screw-compatible crimp-on terminals with an insulation sleeve, as shown below




Torque : 0.4 N.m (4kgf.cm)

5. Avoid to install controller in following spaces :
 - I. A place where the ambient temperature may reach beyond the range from 0 to 50°C
 - II. A place where the ambient humidity may reach beyond the range from 50 to 85% RH.
 - III. A place where the the controller likely to come into contact with water ,oil , chemicals ,steam and vapor.
 - IV. A place where the controller is subject to interface with static electricity ,magnetism and noise.
6. For thermocouple(TC) input ,use shield compensating lead wire.
7. For RTD input ,use shield wires which have low resistance and no resistance difference between the 3 wires.


2 External Dimension and Panel Cutout (Unit : mm)

<p>FZ400</p>		
<p>FZ600</p>		
<p>FZ700</p>		
<p>FZ800</p>		
<p>FZ900</p>		

FZ600 / FZ800




FZ900



5 Operations


1. Power ON:

Controller will display as following






2. Change the Set Value(SV):

Change SV from 0.0 to 100.0




3. Autotuning (AT):

Use AT function to automatically calculate and set the optimize PID value for your system.



4. Change the Alarm value:

Change AL1 value to "5.0" (AL1 active, if PV exceeds SV over 5.0)




* There are total 16 alarm mode types, referenced as below:

* To change Alarm mode, press \rightarrow + \leftarrow key 5 seconds to enter Level 3 (Input Level) and then change the value of ALD1/ALD2/ALD3.

5. Alarm mode type (Referenced for ALD1/ALD2/ALD3)


(▲:SV △:Alarm set value)



*Hold action:
 When Hold action is ON, the alarm action is suppressed at start-up until the measured value(PV) enters the non-alarm range.

*System failed:
 It means that the controller display error message with one of following : "UUU1" or "NNN1" or "CJCE"

3 Parts Description




SYMBOL	NAME	FUNCTION
PV ①	Measured value (PV) display	Displays PV or various parameter symbols (Red)
SV ②	Setting value (SV) display	Displays SV or various parameter set values (Green)
SET ③	Set key	Used for parameter calling up and set value registration
A/M ④	Auto/Manual key	Switches between Auto(PID) output mode and Manual output
< ⑤	Shift key	Shift digits when settings are changed
∨ ⑥	Down key (*Program Hold)	Decrease numbers <i>(*Only for programmable controller)</i>
∧ ⑦	Up key (*Program Run)	Increase numbers <i>(*Only for programmable controller)</i>


SYMBOL	NAME	FUNCTION
OUT1 ⑧	OUT1 lamp	Lights when OUT1 is on (Green)
OUT2 ⑨	OUT2 lamp	Lights when OUT2 is on (Green)
AT ⑩	Autotuning lamp	Lights when Autotuning is activated (Orange)
AL1 ⑪	Alarm 1 lamp	Lights when Alarm 1 is activated (Red)
AL2 ⑫	Alarm 2 lamp	Lights when Alarm 2 is activated (Red)
AL3 ⑬	Alarm 3 lamp	Lights when Alarm 3 is activated (Red)
MAN ⑭	Manual output lamp	Lights when manual output is activated (Red)
PRO ⑮	*Program Running lamp	*Flashes when program running <i>(Only for programmable controller)</i>
OUT1% ⑯	Output% Bar-Graph display	Output% is displayed on 10-dot LEDs

4 Terminal Arrangement

FZ400




FZ700



6 Parameter List

Levels Diagram



Parameter	Default Value	Description
-----------	---------------	-------------

Level 1 (User Level)

- PV** Process Value
- SV** Set Value
- OUTL** Output Limit (Default: 100)
- AT** Autotuning (Default: YES/NO)
- AL1** Alarm 1 set value (Default: 0)
- AL2** Alarm 2 set value (Default: 0)
- AL3** Alarm 3 set value (Default: 0)

Display if output2 is provided

Level 2 (PID Level)

- P1** Proportional band 1 (For output 1) Range: 0.0~200.0% ON/OFF control if set to 0 (0.0)
- I1** Integral time 1 (For output 1) Range: 0~3600 seconds PD control if set to 0
- D1** Derivative time 1 (For output 1) Range: 0~900 seconds PI control if set to 0
- db 1** Dead-band time Don't care
- ATVL** Auto tuning offset value Range: 0~USPL
- CYT1** Output 1 cycle time Range: 0~150 seconds Relay output: 10 Voltage pulse output: 1, mA output: 0
- HYS1** Hysteresis for output 1 ON/OFF control Range: 0~1000
- P2** Proportional band 2 (For output 2) The same with P1
- I2** Integral time 2 (For output 2) The same with I1
- D2** Derivative time 2 (For output 2) The same with D1
- CYT2** Output 2 Cycle time The same with CYT1
- HYS2** Hysteresis for output 2 ON/OFF control The same with HYS1
- GAP1** Control gap 1 (For output 1) Set point of output 1 (Heating side) =SV - GAP1
- GAP2** Control gap 2 (For output 2) Set point of output 2 (Cooling side) =SV + GAP2
- LCK** Function lock (Default: 0000)

Level 3 (Input Level)

- INP1** Input type selection (Default: K2)
- ANL1** Analog input low limit calibration (Used for mA and V input) Range: -1999 ~ 9999
- ANH1** Analog input high limit calibration (Used for mA and V input) Range: 0 ~ 9999
- DP** Decimal point position (Available for mA and V input) 0000 · 000.0 · 00.00 · 0.000
- LSPL** Lower Set-Point Limit (Default: 0.0) Scaling Low Limit
- USPL** Upper Set-Point Limit (Default: 400.0) Scaling High Limit
- ANL2** Remote input low limit calibration Range: -1999 ~ 9999
- ANH2** Remote input high limit calibration Range: 0 ~ 9999
- ALD1** Alarm mode of AL1 Range: 00~19 "Alarm mode type"
- ALT1** Alarm time of AL1 Range: 0~99 Min 59 Secs 0=Flicker Alarm, 99=59=Continued Others=On delay time (If ALD=07, ALT means alarm on time)
- ALD2** Alarm mode of AL2 The same with ALD1
- ALT2** Alarm time of AL2 The same with ALT1
- ALD3** Alarm mode of AL3 The same with ALD1
- ALT3** Alarm time of AL3 The same with ALT1
- HYSA** Hysteresis of all Alarm Range: 0~1000
- CLO1** Output 1 low limit calibration (Used for mA and V output) Range: 0 ~ 9999
- CHO1** Output 1 high limit calibration (Used for mA and V output) Range: 0 ~ 9999
- CLO2** Output 2 low limit calibration (Used for mA and V output) The same with CLO1
- CHO2** Output 2 high limit calibration (Used for mA and V output) The same with CHO1
- CLO3** Retransmission low limit calibration The same with CLO1
- CHO3** Retransmission high limit calibration The same with CHO1
- RUCY** Full run time of proportional motor (Used for proportional motor valve control output) Range: 5~200 seconds
- WAIT** Used for programmable controller to wait continued operation 0=Not wait Others=Wait value
- IDNO** ID number Range: 0 ~ 99
- BAUD** Baudrate 110 / 300 / 1200 / 2400 / 4800 / 9600 bps
- SVOS** SV compensation Range: -1000~1000
- PVOS** PV compensation Range: -1000~1000
- UNIT** Unit of PV & SV C(°C) / F(°F) / A(Analog)
- SOFT** Soft Filter (Default: 0.200)
- OD** Action mode (Default: HEAT) Heat / Cool
- OPAD** Control algorithm (Default: PID) PID / Fuzzy
- HZ** Frequency (Default: 60) 50 / 60HZ

LCK	Levels entering available			Parameters which can be changed
	Level 1 (User Level)	Level 2 (PID Level)	Level 3 (Input Level)	
0000	○	○	○	All parameters (Factory set value)
1111	○	○	---	All parameters
0100	○	○	---	All parameters except Level 3
0110	○	○	---	Parameters in Level 1
0001	○	○	---	"SV" and "LCK"
0101	○	○	---	Only "LCK"

7 Error Displays

in 1E	IN1E : Input 1 Error Check whether input loop is opened or wiring incorrect.
CJCE	CJCE :Cold Junction Compensation Failed Check the compensation diode outside controller.
UUU1	UUU1 : PV is above USPL Check whether the input value is correct or not.
NNN1	NNN1 : PV is below LSPL Check whether the input value is correct or not.
ADCF	ADCF :A/D Convert Failed Controller needs to be repaired.
RAMF	RAMF :RAM Failed Controller needs to be repaired.

